


PRODUCT NAME : Spoke ITEM NUMBER: E21026-MW


Please consult your electrician for hanging fixture and wiring.





IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation

(B)


Canopy









Locate all hardware & components before discarding packaging







Step.1: Run wire through the stems (C) and combine stem lengths to desired mounting height.



Step.2: Remove the mounting bracket (A) from canopy and install to electrical box.



Step.3: Wire fixture to wires in outlet box. Install green wire to ground screw.



Step 4: Install canopy (B) to bracket (A) and tighten screws at the ends of canopy to secure.

Cleaning & Care:

Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.